

Optimum TV Quick Tips



Keep your TV picture perfect

Make sure your TV and cable box are plugged in and powered on. Then check that the TV is on the correct input for the cable box by pressing the **TV/VIDEO, INPUT** or **SOURCE** button on your TV manufacturer's remote control. The input selected must match the input you used to connect your digital cable box to your TV.

Find programs in a snap

Press **GUIDE** ▶ Use the **ARROW** buttons to highlight programming and view the description ▶ Press **SEL** to watch, record or get more information.

Using Multi-Room DVR

Record a program:

Tune to the program you want to record ▶ Press **REC** ▶ Select **RECORD** in Recording Options.

Watch a recorded program:

Press **DVR** ▶ Highlight a program and press **SEL** ▶ From the right-hand menu, select **PLAY** to begin watching.

Enjoy the best HD viewing experience

Go to optimum.net/tvquality to view the setup instructions or to watch a tutorial.

Channels to remember

Ch. 900: Explore Optimum

Ch. 14: Optimum Channel

Ch. 500: On Demand

Get more answers

 facebook.com/Optimum

 optimum.net/emailus

 optimum.net/chat

 twitter.com/OptimumHelp

 youtube.com/Optimum